


## **METABOX** Drawer Adjustments


## Regular Drawer - Height Adjustment



1. Loosen Cam.

Deep Drawer - Gallery Rail Adjustment


bottom of clip.



- 1. Insert gallery rail into front.
- 2. Swing open to fasten.
- 3. Clip gallery rail on at back.

## Tilt Adjustment


4. Close clip to tighten front.



## Gallery Removal

3. Tighten screws.

± 1.5 mm



- 1. Detach gallery at back.
- 2. Swing parallel to front.
- 3. Pull out dowel.